









1800
1886

115
768
42

925



50
1500 900 600 900

3050

2067
512
330
300
925

1184
768
115
2067

← Schrank von der
Stirn-Seite zu öffnen

50 600 600 300 900 600 450 445

1250 1800 895

3950

